

Hydraulic Adapter Sleeve Disassembling

•Adapter sleeve over 140 mm bore – (32).
Example: OH 2332

- Untighten the nut using a hook spanner, remove the washer, replace the nut, by some turns.
- It is necessary that the adapter nut is tapped on the sleeve as a limiter, not to let the bearing to leave completely. This procedure must be done before pumping oil to the sleeve.
- Tap the hose connection on the sleeve thread to let the oil between the sleeve and the bearing.
- Pump oil until the bearing moves out of the sleeve.

